

REVISION HISTORY

NUMBER	DATE	DESCRIPTION	NAME
2.8.5.1685 2.8.5.1711- 1711+g1c4ab78c6	2026-10-30	Current release snapshot of Network UPS Tools (NUT).	
2.8.5	2026-04-07	Some changes to docs and recipes, especially for parallel builds; introduced a way to build with private shared libraries to save space. Updated NUT SEMVER definition some more, added a normalization and comparison script. Some rounds of code-hardening project. Added reference RPM/DEB recipes to test NUT iterations on OBS. Numerous driver updates, some new ones introduced.	JK
2.8.4	2025-08-07	Fixed a few regressions introduced by release v2.8.3. Some changes to docs and recipes, especially for parallel builds. Updated NUT SEMVER definition some more. Some rounds of code-hardening project. Numerous driver updates, some new ones introduced.	JK
2.8.3	2025-04-07	Some changes to docs and recipes, libupsclient API and functionality. Updated NUT SEMVER definition and added scripting around it. Groundwork for vendor-defined status and INSTCMD buzzwords like "ECO". Fixed some regressions and added improvements for certain new device series.	JK
2.8.2	2024-04-01	Some changes to docs and recipes, libnutscan API and functionality. Added nutconf (library and tool). Fixed some regressions and added improvements for certain new device series.	JK
2.8.1	2023-10-31	Some changes to API, docs and recipes, in particular to simplify local builds and tests (e.g. to help end-users check if current NUT codebase trunk has already fixed an issue they see with a packaged installation). Revived NUT for Windows effort, further improved other OS integrations. NUT became reference for "UPS management protocol", Informational RFC 9271. Documentation files refactored to ease maintenance. More drivers and new driver categories introduced.	JK

REVISION HISTORY

NUMBER	DATE	DESCRIPTION	NAME
2.8.0	2022-04-26	Change of maintainer. Many changes to API, docs (both style and content), and recipes, with a stress on non-regression test-ability, run-time debug-ability, general codebase maintainability, as well as OS integrations (notably nut-driver-enumerator for systemd and SMF service instance maintenance). Added a lot in area of CI support and documented pre-requisite package lists for numerous platforms, and CI agent set-up. Added libusb-1.x support and many new driver categories (and drivers), and daisychain device connection support. Instant commands enhanced with TRACKING to enable protocol-based waiting for completion of a particular INSTCMD or SET operation.	JK
2.7.4	2016-03-09	NUT variables namespace updated, in particular for outlet groups, alarms and thresholds, ATS devices, and battery.charger.status to supersede CHRG and DISCHRG flags published in ups.status readings. NUT network protocol extended with NUMBER type; some API changes.	AQ
2.7.3	2015-04-22	Documentation revised, including some API changes. Added NUT DDL links. NUT variables namespace updated.	AQ
2.7.2	2014-04-17	The nut-website project was offloaded into a separate repository. FreeDesktop HAL support was removed (obsoleted in GNOME consumer). Introduced nutdrv_atcl_usb driver.	AQ
2.7.1	2013-11-19	NUT source codebase migrated from SVN to Git (and from Debian infrastructure to GitHub source code hosting). jNut binding split into a separate project. Introduced libnutclient (C++ binding), al175, apcupsd-ups and nutdrv_qx drivers, Mozilla NSS support for simpler licensing than OpenSSL, and a newer apcsmart implementation. Documentation support enhanced with a spell checker, contents massively updated to reflect project changes.	CL

REVISION HISTORY

NUMBER	DATE	DESCRIPTION	NAME
2.6.5	2012-08-08	New macosx-ups driver, new implementation of mge-shut driver. NUT variables namespace updated. Docs cleaned up and revised.	AQ
2.6.4	2012-05-31	New NUT network protocol commands (LIST CLIENTS, LIST RANGE and NETVER), and socket protocol commands (ADDRANGE, DELRANGE). NUT variables namespace updated. Introduced nut-recorder tool.	AQ
2.6.3	2012-01-04	No substantial changes to documentation.	AQ
2.6.2	2011-09-15	Introduced nut-scanner tool and nut-ipmipsu driver, systemd support, and a new apcsmart implementation.	AQ
2.6.1	2011-06-01	Introduced default.* and override.* optional settings in ups.conf, an ups.efficiency report, and outlet.0 special handling.	AQ
2.6.0	2011-01-14	First release of AsciiDoc documentation for Network UPS Tools (NUT).	AQ


Contents

1	APC	1
1.1	940-0024C clone	1
1.2	940-0024E clone	1
1.3	940-0024C clone for Macs	1
2	Belkin	2
2.1	OmniGuard F6C***-RKM	2
3	Eaton	2
3.1	MGE Office Protection Systems	2
3.1.1	DB9-DB9 cable (ref 66049)	2
3.1.2	DB9-RJ45 cable	3
3.1.3	NMC DB9-RJ45 cable	4
3.1.4	USB-RJ45 cable	4
3.1.5	DB9-RJ12 cable	5
3.2	Powerware LanSafe	7
3.3	SOLA-330	7
4	HP - Compaq	8
4.1	Older Compaq UPS Family	8
5	Phoenixtec (Best Power)	8
6	Tripp-Lite	9
7	Text cable references	9
7.1	APC Back-UPS RS 500 serial cable	10
7.2	APC cable reference	11
7.3	GE, IMV and Victron cable reference	20
7.4	IMV Match19 cable reference	22
7.5	MGE UPS SYSTEMS serial cable reference	23
7.6	Powerware cable reference	24
7.7	Repotec cable reference	25
7.8	SMS cable reference	26

1 APC

1.1 940-0024C clone

From D. Stimits



Note

The original 940-0024C diagram was contributed by Steve Draper.


1.2 940-0024E clone

Reported by Jonathan Laventhol

This cable is said to use the same wiring as 940-0024C clone.

1.3 940-0024C clone for Macs

From Miguel Howard



2 Belkin

2.1 OmniGuard F6C***-RKM


From "Daniel"

A straight-through RS-232 cable (with pins 2-7 connected through) should work with the following models:

- F6C110-RKM-2U
- F6C150-RKM-2U
- F6C230-RKM-2U
- F6C320-RKM-3U

● RS232

Character based protocol



3 Eaton


Documents in this section are provided courtesy of Eaton.

3.1 MGE Office Protection Systems

The three first cables also applies to MGE UPS SYSTEMS and Eaton.


3.1.1 DB9-DB9 cable (ref 66049)

This is the standard serial cable, used on most units.



3.1.2 DB9-RJ45 cable

This cable is used on the more recent models, including Ellipse MAX, Protection Station, ...



3.1.3 NMC DB9-RJ45 cable


The following applies to the MGE 66102 NMC (Network Management Card), and possibly other models. The NMC connection is an 8P8C RJ45-style jack.

Signal	PC	NMC
	1,4,6	
TxD	2	3
RxD	3	6
GND	5	4
	7,8	
	shield	shield

3.1.4 USB-RJ45 cable

This cable is used also on the more recent models, including Ellipse MAX, Protection Station, ...


CABLE :




3.1.5 DB9-RJ12 cable

This cable is used on some older Ellipse models.


Sub D 9 :



RJ 12 :




CABLE :



3.2 Powerware LanSafe


LanSafe for

3115 / 5105 / 5119 / 9110 / 9150 / 9305



3.3 SOLA-330

Just uses a normal serial cable, with pin 1-1 through to 9-9.



4 HP - Compaq

4.1 Older Compaq UPS Family

This cable can be used with the following models:

T700, T1000, T1500, T1500j, T700h, T1000h, T1500h, R1500, R1500j, R1500h, T2000, T2000j, T2400h, T2400h-NA, R3000 / R3000j, R3000h, R3000h-International, R3000h-NA, R6000h-NA, R6000i, R6000j.

UPS	PC	9 pin connector
1 -----	3	
2 -----	2	
	4 -\	
4 -----	5	
	6 -/	
6 -----	7	

Contributed by Kjell Claesson and Arnaud Quette.

5 Phoenixtec (Best Power)

Many Best Power units (including the Patriot Pro II) have a female DB-9 socket with a non-standard pinout.

Signal	PC	UPS
	1,4,6	NC
TxD	2	2
RxD	3	1
GND	5	4
	7,8	NC


Sources:

- http://pinoutsguide.com/UPS/best_power_pinout.shtml
- http://lit.powerware.com/lit_download.asp?file=m_patriotproii_jan99.pdf
- Stan Gammons

6 Tripp-Lite

From Tripp-Lite, via Bryan Kolodziej

This cable (black 73-0844 cable) is used on various models, using the "Lan 2.2 interface" and the genericups driver (upstype=5).



7 Text cable references

The following original text references retain their pin diagrams, notes and contributor attribution.

7.1 APC Back-UPS RS 500 serial cable

Desc: APC UPS cable - for Back-UPS RS 500

File: apc-rs500-serial.txt

Date: 14 July 2004

Auth: Russell Kroll <rkroll@exploits.org>, Martin Edlman <edlman@fortech.cz>

This document was constructed from a mail from Martin. He figured out the pinouts to make the Back-UPS RS 500 work with a normal serial port. Here are the details:

UPS side	PC side
RJ45 (8 pins)	DB9F
1 orange/white	2,8,9
2 orange	1
3 green/white	chassis/ground
4 blue	-
5 blue/white	-
6 green	5
7 brown/white	4,6
8 brown	-

```

      +---+
+-----+ +-----+
|           |
+-----+
 8 7 6 5 4 3 2 1

```

view from back (cable entry)

Note this results in OL=-CTS, LB=DCD, SD=ST, CP=RTS, so it should work with the existing genericups type 20.

7.2 APC cable reference

Desc: APC UPS cables

File: apc.txt

Date: 12 February 2010

Auth: Arjen de Korte <adkorte-guest@alioth.debian.org>

<http://lists.alioth.debian.org/pipermail/nut-upsuser/2005-August/000118.html>

Note that APC UPS serial cable part numbers follow a numbering scheme where the "940-" prefix identifies them as cables.


940-1000	straight through cable
940-0103	null modem cable
940-0020	Basic Signaling Cable (OB and kill power)
940-0023	Simple Signaling Cable (OB only)
940-LL24	Smart Signaling Cable
940-0095	PnP Cable (see Apcupsd manual for diagram)
940-0119	Simple Signaling Cable (OB and kill power)
940-0127	RJ45-10P10C to USB Cable
940-0128	Simple Signaling Cable for Back-UPS CS

"LL" represents the length:

00	six feet
NN	NN feet

The suffix letter represents a minor revision in physical design, or a change of OEM, not a change of wiring or pin-out, and all cables differing only in this suffix letter are electrically interchangeable. Note though the following quote from the APC Discussion Forums: "At one point there were a small number of revision D cables [940-0024D] that had some shielding issues from the manufacturer that could maybe cause [...] [spontaneous] self-tests)."

Black APC 940-0024C Smart Signalling UPS Cable Wiring Diagram
This information is verified and tested to be 100% correct.



Operation: The UPS communicates with the Computer via ordinary RS-232 serial protocol at 2400-8N1 with software flow control. Jumpered pins in the DB9F connector are for automatic or PNP cable identification by UPS software.

	Male (pins)	Female (holes)
DB9 RS-232 PC type connector	1 5	5 1

Pinout numbering	\ /	\ o o o o o /
looking into the	\ /	\ o o o o o /
end of the cable	-----	-----
	6 9	9 6
NOTE: Solder a wire to the metal shell for use as a FRAME-GND		
+-----+		

```

Gray APC 940-0020B Simple Signalling UPS Cable Wiring Diagram
This information is verified and tested to be 100% correct.
-----
DB9M(UPS)                2m Cable                DB9F(Computer)
-----                -----                -----

(SHELL) <-----+-----//-----+-----< (SHELL)
                |                |
CHASSIS 9<--+      -      -
                |  |            |  |
COMMON 4<--+-----//-----<5 SG
                |  |            |  |
POWER-FAIL 2<-----//-----<8 CTS
                |  |            |  |
SHUTDOWN 1<-----//-----<4 DTR
                |  |            |  |
BATTERY-LOW 5<-----//-----47K--+--47K--+--<7 RTS
                |  |            |  |
                -      -      |  E  |
NOTES:                |B  |<--+
RTS must be held at +V SPACE.                +---|
TXD must be held at -V MARK.                2N3906 |---+--<1 DCD
All resistors are 5% 1/8W CF.                C  |
Cable type is shielded 28AWG.                4K7
The DB shells are connected                |
to each other via the shield.                +---<3 TXD

```


NOTES:	B	<--+
RTS must be held at +V SPACE.	+---	
TXD must be held at -V MARK.	2N3906	---+---<1 DCD
All resistors are 5% 1/8W CF.		C
Cable type is shielded 28AWG.		4K7
The DB shells are connected		
to each other via the shield.		+---<3 TXD

Operation: The UPS communicates with the Computer via the RS-232C handshaking lines only, and does not use any serial protocol. Upon power fail, the UPS forces CTS to -V MARK. When the battery is low, the UPS forces DCD to +V SPACE via the transistor. When the Computer forces a +V SPACE on DTR, the UPS will shut down and turn off. Presence of the cable can be sensed by signaling on TXD while monitoring DCD.

	Male (pins)		Female (holes)	
DB9 RS-232 PC type connector	1	5	5	1
-----	<hr/>		<hr/>	
Pinout numbering	\ /		\ o o o o o /	
looking into the	\ /		\ o o o o o /	
end of the cable	-----		-----	
	6	9	9	6

NOTE: Solder a wire to the metal shell for use as a FRAME-GND

Gray APC 940-0095A Smart Signalling UPS Cable Wiring Diagram
 This information is verified and tested to be 100% correct.



Operation: The UPS can communicate with the Computer solely via the RS-232C handshaking lines, or via RS-232C serial protocol at 2400-8N1 with software flow control. Upon power fail, the UPS forces RI to -V MARK. When the battery is low, the UPS forces DCD to +V SPACE via the transistor. When the Computer forces a +V SPACE on RTS, the UPS will shut down and turn off. Jumpered pins in the DB9F connector allow for automatic automatic or PNP cable identification by UPS software.

	Male (pins)		Female (holes)	
DB9 RS-232C PC type connector	1	5	5	1
Pinout numbering looking into the end of the cable	\ /		\ o o o o o /	
	\ /		\ o o o o o /	
	-----		-----	
	6	9	9	6

NOTE: Solder a wire to the metal shell for use as a FRAME-GND

```

APC 940-1000 Straight Through cable
Universal APC serial extension cable for use in conjunction
with an APC UPS cable. This cable is verified to work.
-----
DB9M to UPS cable      Shielded Cable      DB9F to Computer
-----      --- 28AWG ---      -----
(SHELL) <-----+-----//-----+-----< (SHELL)
                |                |
                -                -
                | |              | |
1<-----//-----<1 DCD
                | |              | |
2<-----//-----<2 RXD
                | |              | |
3<-----//-----<3 TXD
                | |              | |
4<-----//-----<4 DTR
                | |              | |
5<-----//-----<5 SG
                | |              | |
6<-----//-----<6 DSR
                | |              | |
7<-----//-----<7 RTS
                | |              | |
8<-----//-----<8 CTS
                | |              | |
9<-----//-----<9 RI
                | |              | |
                -                -
NOTE: The DB shells are connected to each other via the shield.

```

NOTE: The DB shells are connected to each other via the shield.

	Male (pins)	Female (holes)
DB9 RS-232 PC type connector	1 5	5 1

Pinout numbering	\ /	\ o o o o o /
looking into the	\ /	\ o o o o o /
end of the cable	-----	-----
	6 9	9 6
NOTE: Solder a wire to the metal shell for use as a FRAME-GND		
+-----+		

7.3 GE, IMV and Victron cable reference

Desc: IMV Victron UPS cables

File: victron.txt

Date: 13 April 2002

Auth: Daniel Prynych <Daniel.Prynych@hornet.cz>

Data cable 1 for UPS:

GE/IMV/Victron Match - 500 700 700L 1000 1000L 1500 2200 3000

GE/IMV/Victron NetPro (NetPro 19 ") - 600 1000 1200 2000 3000 4000

Driver: victronups (newvictronups)

UPS	PC 9 pin connector
1 -----	3
2 -----	2
5 -----	5 GND
	4 DTR
	1 DCD

Data cable 2 for UPS:

GE/IMV Victron Match Lite (all types)

Driver: victronups (newvictronups)

UPS	PC 9 pin connector
2 -----	3
3 -----	2
4 -----	5 GND
	4 DTR
	1 DCD

Crack cable: for UPS

Victron Lite (no IMV Victron Match Lite)

Driver: genericups

```

UPS          PC 9 pin connector
1 ----- 4 DTR
7 ----- 1 DCD -----+
9 ----- 8 CTS -----+   |
5 ----- 5 GND           |   |
                        |   |
                        R   R 6,8k - 10k ohm
                        |   |
                        7 RTS-----+-----+

```

 GE is General Electric Company.

On July 31, 2001, the General Electric Company, acquired IMV (Victron) company.

7.4 IMV Match19 cable reference

Desc: IMV Match19 700 - 1500
 File: imv.txt
 Date: 06 April 2002
 Auth: Niels S. Richthof <niels@richthof.de>

"UPS-VIC23-2" PC 9 pin connector

1	-----	3
2	-----	2
4	-----	7
5	-----	5

7.5 MGE UPS SYSTEMS serial cable reference

Desc: MGE UPS SYSTEMS serial cable

File: mgeups.txt

Date: 10 April 2002

Auth: Arnaud Quette <arnaud.quette@free.fr> or <arnaud.quette@mgeups.com>

This document describes the cable for MGE smart protocols : UTalk (ASCII), and SHUT (Serial HID UPS Transfer, binary) .

First notice that MGE UPS SYSTEMS supply a standard cable, bundled with the UPS unit and compatible with MS Windows and Unices (Ref 66049). For more information, see below note about serial cable, PnP and Unix.

Cable description

UPS		COMPUTER
MALE DB9		FEMALE DB9
2	-----	2 TX
3	-----	3 RX
5	-----	5 GND
		-- 4
		-- 6
		-- 7
		-- 8

UPS connector description

5	4	3	2	1

\o	o	o	o	o/
\	o	o	o	o/

9	8	7	6	

9 pin Male DB-9 connector on UPS

Notes

- this is a universal serial cable, so it should work with any MGE serial model.
- max. length of cable is 1,80 m.
- Computer pin 6 (RTS) is reserved for PnP use, which could trouble communication on some Unices if cabled. However, new models (such as Ellipse, Evolution, Pulsar and Comet EXtreme, EXtreme C, ...) handle this, so you can safely cable pin 6 or use a standard (bundled) "windows" cable (Ref 66049).

7.6 Powerware cable reference

Desc: Powerware 3115 factory cable
File: powerware.txt
Date: 22 July 2005
Auth: various

1) Powerware 3115 factory cable
From Peter Åstrand <altic@lysator.liu.se>


UPS	PC 9 pin connector
5 -----	1
2 -----	2
1 -----	3
4 -----	5
6 -----	8

2) Powerware 5119 RM Cable Layout
From Daniel Thompson <danht@callthenet.com>

UPS <----->	PC
DB9-M <----->	DB9-F
Pin 1 <----->	Pin 3
Pin 2 <----->	Pin 8
Pin 4 <----->	Pin 4
Pin 5 <----->	Pin 1
Shells Grounded Both Ends	

7.7 Repotec cable reference

Desc: Repotec 800A (800VA) & 162A (1600VA) cable
 File: repotec.txt
 Date: 11 April 2001
 Auth: Theodor Milkov <zimage@delbg.com>



7.8 SMS cable reference

Desc: SMS UPS cables, for Upsilon compatible SMS UPS
File: sms.txt
Date: 9 October 2001
Auth: Marcio Gomes <tecnica@microlink.com.br>

COMPUTER		UPS
FEMEA DB9		MACHO DB9
2	-----	6
3	-----	9
4/8	-----	5
5	-----	8

- This cable is working with Manager III 1300 VA and 650 VA, SMS UPS's
 - Jump in computer side pins 4/8 and connect to pin 1 in UPS side
 - Use NUT blazer_ser driver
-