GS510Pro Gaming Headset User Manual		
Product Features	• 3 Modes Connection-Bluetooth/2.4Ghz Wireless/3.5mm Jack Wired Connection • 3 Professional Audio Modes -Gaming/Live/Music Mode • Retractable & 120° Rotting Microphone • Magnetic Speaker Tags Design • Virtual 7.1 Surround Sound • 8 RGB Lighting Effects + One Multi-color Cycling Mode	
Package Contents	• 1 x Cat Ear Headphone • 2 Pair x Speaker Tags • 1 x USB Transmitter • 1 x 3.5 mm Splitter Cable • 1 x Type-C Charging Cable • 1 x User Manual	
Specifications	Model	GS510 Pro
	Bluetooth version	5.0
	Driver Diameter	Ø50mm
	Directivity(Mic)	Unidirectional
	Sensitivity(Mic)	36dB±3dB
	Impedance(Mic)	≤2.2KΩ
	Impedance (Headphones)	32Ω
	Sensitivity(Headphones)	100±3db
	Frequency Response(Headphones)	20Hz ~ 20KHz
	Headset Battery Capacity	1500mAh
	Battery Working Time	8 Hours
	Battery Charging Time	2 Hours
	Communication Distance	10 Meters/33 Feet

Headset Controls	**Power On/Off** In the off state, long press the power button for 2 seconds, the headset will automatically turn on. In the power-on state, press and hold the power button for 3 seconds, the headset will automatically turn off. **Audio Mode Switch** Short press the “mode” button once to switch the sound effect mode. Green light: Gaming Mode/ White light: Music Mode/ Blue light: Live Mode **Music Pause/Play** Short press the power button once to pause/play the music. **Call Mode** When a call comes in, short press the power button once to answer the call. When a call comes in, short press the power button twice to reject the call. During a call, short press the power button once to hang up the call. **Light On/Off** Three-click the lighting touch key to turn on/off the headset light. **Light Color Switch** Press the lighting touch key for 2 seconds to switch the light color. **Charge** 1. When the headset is charging, the battery indicator shows a solid orange light. When the headset is fully charged, the battery indicator shows a solid green. 2. When the power of the headset is less than 10%, the headset will emit a "Please Charge" prompt, please charge it in time.

Quick Start Guide	**Connect Headphones to Device via Bluetooth (Compatible with Smartphone)** 1. Long press the headphone power button for 2 seconds, release the button after the light is always on, and the headset powered on successfully. 2. When the power on is successful, the headset automatically enters the pairing state, and the power on indicator light will rapidly blink blue. 3. Open the Bluetooth settings when you connect the headset for the first time, search and select the device"SOMIC STINCOO GS510", and the power-on indicator will be solid blue after the connection is successful (The headset will automatically connect to your phone after being paired the first time) 4. If the connection fails, it will automatically enter the re-pairing mode. If there is no device available within 3 minutes, the headset will automatically shut down. ★**Notes:** If connection fails, please try again after fully charging. **Connect Headphones to Device via USB Transmitter (Compatible with PC, PS5, PS4, PS4 Pro, Laptop, MAC)** **Automatic Connection** 1. Insert the USB transmitter into the USB port of you device, the blue indicator of the USB transmitter flashes. 2. Long press the power button for 3 seconds to turn on the headset, when the headset light is on, and the power is successful. 3. The USB transmitter automatically connect to the headset. When the Blue light of the USB transmitter is always on, the connection is successfully. 4. If automatic connection fails, please try the below way. **Manual Connection** 1. Turn on the headset. Then insert the USB transmitter into the USB port of you device and the blue indicator of the USB transmitter flashes. 2. Insert a small pin into the reset hole (next to the LED indicator) on the USB transmitter, then push in for 2 seconds until the LED light rapidly blinks blue. 3. The USB transmitter automatically connect to the headset. When the Blue light of the USB transmitter is always on, the connection is successfully. ★**Notes:** 1. If connection fails, please try again after fully charging.

	2. Please disconnect the Bluetooth connection of mobile phone first when you connect the headphones to device via the USB transmitter. 3. If you need to reset the factory setting, please hold the power button for 10 seconds with the headset off, after hearing a tone, it means that the factory settings have been reset. **Connect Headphones to Device via 3.5mm Audio Cable (Compatible with PS5/PS4/Xbox One/Xbox Series X/S Controller/Nintendo Switch)** 1.Connect the 3.5mm audio cable (Package included) between the headset with other devices that with 3.5mm jack. For old Xbox one, a Microsoft adapter is required (not included) ★**Notes:** In wired mode, the headset light don't work, all buttons are disable except for adjusting the volume+/-.
Caution	1. This product is compatible with Microsoft Windows 7/8/10, Apple Mac OS system, Android system and IOS system. 2. If it is not available on the operating system or equipment that is not listed, you can contact the support team for help. 3. When using the headset, if there is no sound from the microphone or headset itself, it may be caused by compatibility problems or improper use, and you can contact our after-sales service for help. 4. If any part is damaged, such as a broken cable, please stop using it and contact the after-sales service for help to avoid unnecessary losses. 5. If the headset does not respond for a long time, you can use a small pin into the hole on the wireless USB Dongle, then push in for at least one second. the headset can be forced to shut down. 6. If you want to know more information, please visit Somic's official website www.itsomic.com
Warranty	SOMIC products are covered by a 12 months limited warranty from the date of its original purchase. If any problem occur, please contact our support team, we will always be here to help you solve the problem. If you want to know more information, please visit Somic' s official website www.itsomic.com.