




BOULT AUDIO

Boult Audio Airbass Z1 User Manual

For better sound quality experience, suggest use
IOS 8.0/ Android 4.3 or above operating system.

Product Picture



Charging LED Indicator

Type-C charging port

Smart finger touch



Earbuds sounds hole



Pods charging point



Manual




Earbud



USB Cable

Power On


1. Take the earbuds out of case, they will automatically turn on and pair with each other.



2. 5 Second long press on Right & Left earbuds MTF manually.

Power Off

1. 8-Second Long-press on R & L earbuds MTF (Manually).
2. Put the earphone into the charging box.
close the cover then power off.



Pairing

For the first time pairing, take the earbuds out of case and search bluetooth "Boult Audio Airbass" on your cell phone and tap to connect.




Regular use:

Once next use, the earbuds will automatically connect with a preconnected device.

Resume pairing of left and right earbuds:

Put earbuds in the charging case and charge, then take earbuds out of the charging case when they are charged a few minutes. they will enter into pairing mode automatically.



- Put in the charging case and charge them
- Take out of charging case
- Pairing automatically

Charging

Earbuds:

Put earbuds into charging case, and they will be charged automatically.



Charging Case:

Plug the attached Type-C cable in the Computer or charger, the Red light on indicator flashes when the charging case is being charged, and will keep off light after being fully charged.



Functional Operation

Music

Single-click: Either earbuds Pause/Play.

Double Click: The left earbud for previous songs

Double Click: The right earbud for next song.



Incoming call

Single Click: Either earbud to answer Call.

Double Click: Either earbud to reject / End Call.



Siri Voice assistant

Long Press 3S : Either earbud to activate siri voice assistant.



Tips:

1. The Volume can be adjusted by the phone. Please use the earbud in reasonable volume and time, otherwise it will damage your hearing if you listen the music for long time in high volume. 2. In the Mono mode, double click the earbud only for next song.

Attentions

- 1.If the earbuds is left unused for over two weeks, please recharge it periodically.
2. Be sure to use a 5V DC, 1A charger made by qualified manufacturer.
3. Ensure that the distance between your device and the earbuds not too far away, Ensure that nothing is blocking the signal between your device and the earbuds.
4. The implementation of the earbuds function will be different due to different protocols supported by different wireless device.
5. Don't disassemble or modify your earbuds for any reason to avoid any damages and danger. Don't over Charge to avoid the outbreak of a fire. Avoid exposing the earbuds to extreme temperatures (below 0°C or above 45°C). Extreme temperatures can cause deformation of Earbuds components and reduce battery life and the lifespan of your earbuds.
6. Don't put the device's LED lights close to human's or animals' eyes. Do not use the earbuds during a thunderstorm. Thunderstorms can cause serious malfunction and increase the risk of electric shock.
7. Do not clean the earbuds with harsh chemicals or strong detergents.
8. Please follow our company's operating instructions. If any damage or danger caused due to the improper use, the responsibility shall be undertaken by the operator.